

Installation Guide

Bacharach HGM-MZ to LonWorks FT-10 Communications Adapter

NOTE: User resource files are available for download on the Bacharach web site.

Introduction

The Bacharach HGM-MZ to LonWorks FT-10 Communications Adapter enables a Bacharach HGM-MZ Refrigerant Monitor to communicate with a LonWorks FT-10 Free Topology network. Zone PPM readings, flow status, refrigerant selections, and HGM-MZ internal health may be viewed over LonWorks. In addition, each HGM-MZ zone supports three levels of alarming (leak, spill, and evacuate) and each alarm threshold can be set over LonWorks.




Figure 1 – HGM-MZ-to-LonWorks FT-10 Communications Adapter

The LonWorks FT-10 Communications Adapter can be used in conjunction with the MZ-RD remote display if desired. Wiring details and operational limitations when using the MZ-RD are discussed below. For additional information on the Bacharach HGM-MZ, refer to document 3015-5074.

CAUTION: The adapter is powered from the 120/240V universal power supply connection on the HGM-MZ main board. 120/240V is present on the lower left corner of this adapter within the area shown on the board silkscreen. *Keep fingers away from this area when the HGM-MZ is powered.*



Adapter Installation inside the HGM-MZ

The communications adapter board is typically installed in the HGM-MZ at the factory. It can, however, be field installed by following the instructions below.

Step	Instruction
1.	<p>The following installation materials are needed for field installation of the adapter.</p> <p style="padding-left: 40px;">Five (5) 6-32 × ¼" screws</p>
2.	<p>The adapter board mounts on the rear of the HGM-MZ enclosure door. Position the adapter board over the five standoffs on the door and install with the 6-32 × ¼" screws through the board and into the standoffs.</p>
3.	<p>Connect power wiring from the HGM-MZ's 120/240V universal power supply terminal block to the adapter board's AC IN terminal block. Use UL approved wire. Wire polarity does not matter.</p>
4.	<p>If an HGM-RD remote display is NOT used with the adapter, refer to Figure 2 for wiring details. In this case, all wiring is between the HGM-MZ. The only external cable is the LonWorks FT-10 communications cable as shown below.</p> <div style="text-align: center;"> <p style="text-align: center;">Figure 2 – Wiring without Remote Display (Option A)</p> </div>
5.	<p>If an MZ-RD remote display IS to be used with the adapter, refer to Figure 3 for wiring details. Note that when the MZ-RD is used, TWO RS-485 cables must be run between the HGM-MZ and MZ-RD, so plan accordingly.</p>

Switches 5-8 on DIP switch A of the Adapter Board are used to match the node address set on the HGM-MZ's address DIP switch (on the HGM-MZ main board). Values from 0-15 are possible, as shown in the table below.

HGM-MZ Address	Binary Equivalent	DIP Switch A			
		A5	A6	A7	A8
0	0000	Off	Off	Off	Off
1	0001	Off	Off	Off	On
2	0010	Off	Off	On	Off
3	0011	Off	Off	On	On
4	0100	Off	On	Off	Off
5	0101	Off	On	Off	On
6	0110	Off	On	On	Off
7	0111	Off	On	On	On
8	1000	On	Off	Off	Off
9	1001	On	Off	Off	On
10	1010	On	Off	On	Off
11	1011	On	Off	On	On
12	1100	On	On	Off	Off
13	1101	On	On	Off	On
14	1110	On	On	On	Off
15	1111	On	On	On	On

Since the HGM-MZ is the only node on the adapter-to-HGM interface, address 1 is normally used. Be sure to set the same address on the adapter and the HGM-MZ main board DIP switches.

Configuring the HGM-MZ with the MZ-RD or a Laptop PC

The only HGM-MZ parameters that are changeable through LonWorks are the alarm thresholds. Configuring the HGM-MZ for refrigerant type and length of tubing for each zone (zero length to disable a zone) must be done with the MZ-RD remote display or a laptop PC. Refer to the appropriate Bacharach instructions for configuring these items. HGM-MZ's are commonly custom-configured at the factory per the customer's needs, so field configuring these parameters may not be necessary.

If configuring the HGM-MZ with an MZ-RD, the communications adapter's presence will not affect the standard configuration procedure. If configuring with a laptop PC, temporarily disconnect the HGM-MZ's RS-485 cable from the adapter until configuration is complete and the laptop is disconnected.

External Interface (XIF) and User Resource Files

Each adapter comes with a disk containing an External Interface (XIF) and user resource files. The files contain documentation about the network variables contained in the adapter and how they are used. Most network management software will accept XIF files. Echelon LonMaker (and possibly others) will accept user resource files. A subset of the information in these files is permanently stored in the adapter itself and may be queried over the network once the network management software is aware of the node's presence.

Identifying the HGM-LonWorks Adapter on the Network

The adapter can be identified on the network in three ways:

1. If the network management software supports identification by service PIN, the adapter's service pushbutton (directly above the FT-10 twisted pair terminal block—see Figure 1) can be pushed when the network management software requests it. This causes a "here I am" message to be broadcast which should be received by the network manager.
2. The adapter's Neuron chip ID number can be entered manually into the network control PC or handheld tool when requested by the network management software. The Neuron chip ID number is written on the piggyback LonWorks control module in the format XX-XX-XX-XX-XX-XX.
3. If the network management software is capable of finding unconfigured nodes automatically, the Wink command can be sent to the ID of each unconfigured node. Then the nodes can be physically checked to see which node corresponds to which address. When the adapter receives a LonWorks Wink command, it flashes its 1, 2, 3, and 4 status LEDs in unison for approximately 15 seconds.

Alarm Acknowledge Options

Two alarm acknowledge options are supported:

- Auto Acknowledge
- Manual Acknowledge.

In the auto acknowledge mode, the HGM-MZ will clear its alarm outputs the next time the alarmed zone is sampled and its PPM has dropped below the alarm thresholds. No intervention from the LonWorks network is necessary.

In the manual acknowledge mode, the HGM-MZ will never clear its alarm outputs until LonWorks has acknowledged the alarms using network variables **nviHgmAlmAck** or **nviHgmAlmAckSw** (discussed below). Once LonWorks has acknowledged the alarms, the HGM-MZ will clear its alarm outputs the next time the alarmed zone is sampled and its PPM has dropped below the alarm thresholds.

DIP switch A1 on the adapter selects which alarm acknowledge option is used:

- A1 On = auto acknowledge
- A1 Off = manual acknowledge.

If DIP switch A1 is changed while the adapter is powered up, the adapter must be reset by pressing the CPU RST button below DIP switch A before the change will take effect.

Auto Acknowledge Mode

ON = Auto
Acknowledge
OFF = Network
Acknowledge




Figure 5 – Alarm DIP Switch

LonWorks Objects and Network Variables

The adapter contains:

- 1 Node Object
- 16 Zone Objects (one Zone Object for each refrigerant sampling zone)
- 1 General Status Object
- 1 Alarm Control Object.

Object #0 – The Node Object

Network input variable **nviRequest** allows the user to request information from different objects in the node. The **nviRequest** contains an object ID field that specifies which object receives the request. The following request types are supported.




Figure 6 – Node Object #0 Variables

1. **RQ_NORMAL** (value 0) – This request is accepted by any of the objects for compatibility with LonMark requirements, but the request does not cause any change in the objects whatsoever. It does cause the status of the specified object to be reported through **nvoStatus** (works identically to **RQ_UPDATE_STATUS**).
2. **RQ_UPDATE_STATUS** (value 2) – Requests the status of the object specified in the object ID field. If sent to the Object Node (node 0), the status response contains the status bits of all the node objects logically ORed together. The status response is returned through **nvoStatus**.
3. **RQ_REPORT_MASK** (value 5) – Requests the object to report which status bits it supports. All objects support the same status bits, thus the report mask returns the same value no matter which object is requested. The following status bits are supported:
 - **mechanical_fault** for no flow or excessive HGM-MZ internal temperatures
 - **electrical_fault** for HGM-MZ internal electrical faults
 - **unable_to_measure** any time the device can't get HGM-MZ data for whatever reason
 - **comm_failure** HGM-to-adapter failure or adapter internal failure
 - **in_alarm** when sampled PPM exceeds an alarm threshold on any zone

Network output variable **nvoStatus** returns the information requested by **nviRequest**. The status response will indicate the status of the object that received the request. The status bits supported are listed above under **RQ_REPORT_MASK**. One **nvoStatus** response will be returned for each **nviRequest**.

The configuration variable **nciMaxStsSendT** can also be used to automatically send out status updates periodically. If **nciMaxStsSendT** is set to a nonzero time value, the node sends out a status update on each expiration of that amount of time. It rotates through the objects on the node in round-robin fashion when timed updates are sent in this manner. Any zone which is disabled or not installed will have its zone object skipped in this automatic round-robin reporting.

Setting **nciMaxStsSendT** to a very small value will cause unnecessary traffic on the LonWorks network. A value of less than 500 milliseconds will, in fact, be ignored. A suggested value for **nciMaxStsSendT** is in the range of 10-60 seconds. If timed, automatic status updates are not desired, set **nciMaxStsSendT** to zero. Then status updates will only be sent in response to **nviRequest** updates.

Objects #1-16 – Zone Objects

There is one Zone Object for each sampling zone in the HGM-MZ (16 total).

Network output variable **nvoHgmZonePPM** shows the measured gas concentration for a particular zone. The value range is 0-65535 PPM.

Network output variable **nvoHgmZoneStatus** is a text string that displays information about the zone status and the refrigerant type being sensed.

Network output variable **nvoHgmZoneStatus** is a text string that displays information about the zone status and the refrigerant type being sensed.




Figure 7 – Zone Object #1-16 Variables

Possible zone status values are listed below.


Zone Status Value	Description
ZONE NORMAL	No alarms, no faults, HGM-MZ in normal operating mode.
LEAK ALARM	Leak alarm active for this zone.
SPILL ALARM	Spill alarm active for this zone.
EVAC ALARM	Evacuate alarm active for this zone.
ACKD LEAK ALM	Acknowledged Leak alarm active for this zone.
ACKD SPILL ALM	Acknowledged Spill alarm active for this zone.
ACKD EVAC ALM	Acknowledged Evacuate alarm active for this zone.
ZONE FLOW FAULT	This zone has a flow fault (other zones not affected).
CRITICAL FAULT	Critical fault prevents normal zone PPM measurement. See nvoHgmFaults for fault type details.
HGM BUSY	Occurs with RDM800 installed when certain screens are displayed.
COMM FAULT 1	Communications failure between HGM-MZ and adapter.
COMM FAULT 2	Communications failure between adapter internal processors.
HGM WARMING UP	HGM-MZ must go through warm-up cycle after powerup before measuring.
ZONE DISABLED	This zone has tubing length set to 0 (disabled).
NOT_INSTALLED	This zone does not have hardware installed in HGM-MZ.
STARTING UP	Start-up delay after powerup before data available.

Possible refrigerant type values are listed below.

- R11
- R113
- R134a
- R402a
- R408a
- R427a
- R508b
- FA188
- FUTURE3
- NEW1
- R12
- R114
- R227
- R402b
- R409a
- R500
- R717
- FC72
- FUTURE4
- NEW2
- R21
- R123
- R236fa
- R404a
- R410a
- R502
- H1301
- N1230
- FUTURE5
- NEW3
- R22
- R124
- R245fa
- R407a
- R422a
- R503
- H2402
- HFP
- FUTURE6
- R23
- R125
- R401a
- R407c
- R422d
- R507
- H1211
- FUTURE2
- FUTURE7

Object #17 – General Status Object

The General Status Object provides information about any HGM-MZ internal faults present and shows which zone is currently being sampled.



Network output variable **nvoHgmFaultAlert** reports whenever ANY fault is detected within the HGM-MZ or adapter. It is of type SNVT_switch. It is useful for binding to a fault lamp on a remote annunciation panel using a network input variable of type SNVT_switch. When there is no fault, **nvoFaultAlert** will have value=0, state=0. When there is a fault, **nvoFaultAlert** will have value=200, state=1. Depending on the network presentation software, full-scale “value” may display as “200” or “100.0”.

Figure 8 – General Status Object #17 Variables

Network output variable **nvoHgmFaults** (bit field structure) reports various faults within the HGM-MZ or the LonWorks adapter. It contains 14 faults (1-bit fields) that may be reported (0=no fault, 1=fault).

Fault Name	Bit	Description
Clipping Fault	15	Internal HGM-MZ measurement fault (most significant bit)
Zero Fault	14	Internal HGM-MZ measurement fault
No Flow Fault	13	No flow on any zone
Purge Flow Fault	12	No flow during purge cycle
Zone Flow Fault	11	No flow on a particular zone
Trigger Fault	10	Internal HGM-MZ measurement fault
No Zones Fault	9	No zones enabled in HGM-MZ
mA Loop Fault	8	mA loop output [option] is open circuited
Pressure Fault	7	HGM-MZ bench pressure abnormal
Bench Temp Fault	6	HGM-MZ bench temp abnormal
Box Temp Fault	5	HGM-MZ box temp abnormal
HGM Busy	4	If RDM800 attached and showing certain screens
Comm Fault 1	3	Communications failed between HGM-MZ and adapter
Comm Fault 2	2	Internal communications failed within adapter
Unused	1	Unused
Unused	0	Unused (least significant bit)

Network output variable **nvoZoneSampling** shows which zone is currently being sampled by the HGM-MZ. It is a number 1-16. Note that if fewer than 16 zones are installed, **nvoZoneSampling** will never go larger than the largest zone installed. Also, if a zone is disabled (by setting its tubing length to zero), that zone number will be skipped by **nvoZoneSampling**.

Object #18 – Alarm Control Object

The Alarm Control Object provides information about any alarms which are present in the HGM-MZ. It also provides mechanisms for acknowledging alarms, and for viewing and setting the leak, spill, and evacuate alarm thresholds for each zone.

Network input variable **nviHgmAlarmAck** has a single parameter (unsigned short) that specifies which zone alarm the operator wishes to acknowledge. A value of 1-16 acknowledges the alarm for a single specified zone. A value of 0 is a global acknowledge for all zones in alarm.

Network input variable **nviHgmAlmAckSw** is a global alarm acknowledge of standard type SNVT_switch. It is useful for binding to an acknowledge pushbutton on a remote alarm annunciation panel using a network output variable of type SNVT_switch. To acknowledge alarms, set **nviHgmAlmAckSw** to value=200, state=1. Depending on the presentation software, full-scale “value” may be “200” or “100.0”.




Figure 9 – Alarm Object #18 Variables

Network input variable **nviSetZoneThresh** allows leak, spill, and evacuate alarm thresholds (in PPM) to be set for each monitoring zone. Variable **nviSetZoneThresh** has four parameters to be set by the user.

Parameter	Range/Description
Zone Specifier	1-16 (specifies which zone is having its thresholds changed)
Leak Alarm Threshold	0-65535 PPM
Spill Alarm Threshold	0-65535 PPM (larger than leak threshold)
Evacuate Alarm Threshold	0-65535 PPM (larger than spill threshold)

Network input variable **nviGetZoneThresh** accepts a single number 1-16 to specify which zone’s alarm thresholds should be displayed on network output variable **nvoHgmZoneThresh**.

NOTE: Before changing alarm thresholds through **nviSetZoneThresh**, set **nviGetZoneThresh** to the zone you are about to modify. Then **nvoHgmZoneThresh** will update automatically with the current thresholds for that zone every time new information is available from the HGM-MZ.

NOTE: It could take as much as 30-40 seconds before the changes made through **nviSetZoneThresh** can be seen on **nvoHgmZoneThresh**. The adapter must get the changes from LonWorks and pass the new thresholds down to the HGM-MZ. The HGM-MZ then takes a certain amount of time to process the changes and store them in its nonvolatile memory. Then, since the HGM-MZ is not polled continuously, a certain amount of time is needed to pick up the new threshold settings and pass them back up to LonWorks. Please be patient waiting for changed alarm thresholds to show up in **nvoHgmZoneThresh**. Fortunately, changing alarm thresholds is done infrequently after initial installation and setup.

Network output variable **nvoHgmAlarmAlert** reports whenever ANY gas concentration alarm (leak, spill, or evacuate) is generated by the HGM-MZ. It is of type SNVT_switch. It is useful for binding to an alarm lamp on a remote annunciation panel using a network input variable of type SNVT_switch. When there are no alarms, **nvoAlarmAlert** will have value=0, state=0. When there is any alarm, **nvoAlarmAlert** will have value=200, state=1. Depending on presentation software, the full-scale “value” may show as either “200” or “100.0”.

Network output variable **nvoHgmLeakAlert** reports whenever any leak alarm is generated by the HGM-MZ. It is of type SNVT_switch. It is useful for binding to a leak alarm lamp on a remote annunciation panel using a network input variable of type SNVT_switch. When there are no leak alarms, **nvoLeakAlert** will have value=0, state=0. When there are any leak alarms, **nvoLeakAlert** will have value=200, state=1.

Network output variable **nvoHgmSpillAlert** reports whenever any spill alarm is generated by the HGM-MZ. It is of type SNVT_switch. It is useful for binding to a spill alarm lamp on a remote annunciation panel using a network input variable of type SNVT_switch. When there are no spill alarms, **nvoSpillAlert** will have value=0, state=0. When there are any spill alarms, **nvoSpillAlert** will have value=200, state=1.

Network output variable **nvoHgmEvacAlert** reports whenever any evacuate alarm is generated by the HGM-MZ. It is of type SNVT_switch. It is useful for binding to an evacuate alarm lamp on a remote annunciation panel using a network input variable of type SNVT_switch. When there are no Evacuate alarms, **nvoEvacAlert** will have value=0, state=0. When there are any evacuate alarms, **nvoEvacAlert** will have value=200, state=1.

Network output variable **nvoHgmZoneThresh** displays the following information for the zone specified by **nviGetZoneThresh**:

1. Zone (1-16) whose alarm thresholds are being displayed
2. Leak Alarm Threshold in PPM (0-65535)
3. Spill Alarm Threshold in PPM (0-65535)
4. Evacuate Alarm Threshold in PPM (0-65535)

To change the leak, spill, or evacuate alarm thresholds for a zone, use the **nviSetZoneThresh** input network variable as described earlier.

Summary of LonWorks Objects and Associated Network Variables

Obj	I/O	#	Variable Name	Variable Type	Supported Sub Types, Values, Parameters	M/O																																																																
Node (#0)	Input	nv1	nviRequest	SNVT_obj_request	RQ_NORMAL (value 0) RQ_UPDATE_STATUS (value 2) RQ_REPORT_MASK (value 5)	Mandatory																																																																
		nc22	nciMaxStsSendT	SCPTmaxSndT	time value, 0=disabled	Mandatory																																																																
Node (#0)	Output	nv2	nvoStatus	SNVT_obj_status	mechanical_fault electrical_fault unable_to_measure comm_failure in_alarm	Optional																																																																
		nv1	nvoHgmZonePPM	SNVT_ppm	0-65535 PPM	Mandatory																																																																
Zone (#1-16)	Output	nv5	nvoHgmZoneStatus	SNVT_str_asc	ZONE STATUS <table border="0"> <tr> <td>ZONE_NORMAL</td> <td>R12</td> <td>R21</td> <td>R22</td> </tr> <tr> <td>LEAK_ALARM</td> <td>R23</td> <td>R113</td> <td>R114</td> </tr> <tr> <td>SPILL_ALARM</td> <td>R123</td> <td>R124</td> <td>R125</td> </tr> <tr> <td>EVAC_ALARM</td> <td>R134a</td> <td>R227</td> <td>R236fa</td> </tr> <tr> <td>ACKD_LEAK_ALM</td> <td>R245fa</td> <td>R401a</td> <td>R402a</td> </tr> <tr> <td>ACKD_SPILL_ALM</td> <td>R402b</td> <td>R404a</td> <td>R407a</td> </tr> <tr> <td>ACKD_EVAC_ALM</td> <td>R407c</td> <td>R408a</td> <td>R409a</td> </tr> <tr> <td>ZONE_FLOW_FAULT</td> <td>R410a</td> <td>R422a</td> <td>R422d</td> </tr> <tr> <td>CRITICAL_FAULT</td> <td>R427a</td> <td>R500</td> <td>R502</td> </tr> <tr> <td>HGM_BUSY</td> <td>R503</td> <td>R507</td> <td>R508b</td> </tr> <tr> <td>COMM_FAULT_1</td> <td>R717</td> <td>H1301</td> <td>H2402</td> </tr> <tr> <td>COMM_FAULT_2</td> <td>H1211</td> <td>FA188</td> <td>FC72</td> </tr> <tr> <td>HGM_WARMING_UP</td> <td>N1230</td> <td>HFP</td> <td></td> </tr> <tr> <td>ZONE_DISABLED</td> <td colspan="3">FUTURE2-7</td> </tr> <tr> <td>NOT_INSTALLED</td> <td colspan="3">NEW1-3</td> </tr> <tr> <td>STARTING_UP</td> <td colspan="3"></td> </tr> </table>	ZONE_NORMAL	R12	R21	R22	LEAK_ALARM	R23	R113	R114	SPILL_ALARM	R123	R124	R125	EVAC_ALARM	R134a	R227	R236fa	ACKD_LEAK_ALM	R245fa	R401a	R402a	ACKD_SPILL_ALM	R402b	R404a	R407a	ACKD_EVAC_ALM	R407c	R408a	R409a	ZONE_FLOW_FAULT	R410a	R422a	R422d	CRITICAL_FAULT	R427a	R500	R502	HGM_BUSY	R503	R507	R508b	COMM_FAULT_1	R717	H1301	H2402	COMM_FAULT_2	H1211	FA188	FC72	HGM_WARMING_UP	N1230	HFP		ZONE_DISABLED	FUTURE2-7			NOT_INSTALLED	NEW1-3			STARTING_UP				Optional
		ZONE_NORMAL	R12	R21	R22																																																																	
LEAK_ALARM	R23	R113	R114																																																																			
SPILL_ALARM	R123	R124	R125																																																																			
EVAC_ALARM	R134a	R227	R236fa																																																																			
ACKD_LEAK_ALM	R245fa	R401a	R402a																																																																			
ACKD_SPILL_ALM	R402b	R404a	R407a																																																																			
ACKD_EVAC_ALM	R407c	R408a	R409a																																																																			
ZONE_FLOW_FAULT	R410a	R422a	R422d																																																																			
CRITICAL_FAULT	R427a	R500	R502																																																																			
HGM_BUSY	R503	R507	R508b																																																																			
COMM_FAULT_1	R717	H1301	H2402																																																																			
COMM_FAULT_2	H1211	FA188	FC72																																																																			
HGM_WARMING_UP	N1230	HFP																																																																				
ZONE_DISABLED	FUTURE2-7																																																																					
NOT_INSTALLED	NEW1-3																																																																					
STARTING_UP																																																																						
Status (#17)	Output	nv1	nvoHgmFaultAlert	SNVT_switch	Fault: value=200, state=1 No Fault: value=0, state=0	Optional																																																																
		nv2	nvoHgmFaults	SNVT_state	<table border="0"> <thead> <tr> <th>FAULT NAME</th> <th>BIT</th> <th>FAULT NAME</th> <th>BIT</th> </tr> </thead> <tbody> <tr> <td>Clipping fault</td> <td>15</td> <td>Pressure Fault</td> <td>7</td> </tr> <tr> <td>Zero Fault</td> <td>14</td> <td>Bench Temp Fault</td> <td>6</td> </tr> <tr> <td>No Flow Fault</td> <td>13</td> <td>Box Temp Fault</td> <td>5</td> </tr> <tr> <td>Purge Flow Fault</td> <td>12</td> <td>HGM Busy</td> <td>4</td> </tr> <tr> <td>Zone Flow Fault</td> <td>11</td> <td>Comm Fault 1</td> <td>3</td> </tr> <tr> <td>Trigger Fault</td> <td>10</td> <td>Comm Fault 2</td> <td>2</td> </tr> <tr> <td>No Zones Fault</td> <td>9</td> <td>Unused</td> <td>1</td> </tr> <tr> <td>mA Loop Fault</td> <td>8</td> <td>Unused</td> <td>0</td> </tr> </tbody> </table>	FAULT NAME	BIT	FAULT NAME	BIT	Clipping fault	15	Pressure Fault	7	Zero Fault	14	Bench Temp Fault	6	No Flow Fault	13	Box Temp Fault	5	Purge Flow Fault	12	HGM Busy	4	Zone Flow Fault	11	Comm Fault 1	3	Trigger Fault	10	Comm Fault 2	2	No Zones Fault	9	Unused	1	mA Loop Fault	8	Unused	0	Optional																												
		FAULT NAME	BIT	FAULT NAME	BIT																																																																	
Clipping fault	15	Pressure Fault	7																																																																			
Zero Fault	14	Bench Temp Fault	6																																																																			
No Flow Fault	13	Box Temp Fault	5																																																																			
Purge Flow Fault	12	HGM Busy	4																																																																			
Zone Flow Fault	11	Comm Fault 1	3																																																																			
Trigger Fault	10	Comm Fault 2	2																																																																			
No Zones Fault	9	Unused	1																																																																			
mA Loop Fault	8	Unused	0																																																																			
nv3	nvoZoneSampling	UNVT_zone_specifier	1-16 Shows which zone is sampling	Optional																																																																		
Alarm (#18)	Input	nv1	nviHgmAlarmAck	UNVT_zone_specificer	1-16 Acknowledges corresponding zone's alarm 0 global acknowledge (all zones in alarm)	Optional																																																																
		nv4	nviHgmAlmAckSw	SNVT_switch	To Ack, set as follows: value=200, state=1	Optional																																																																
		nv5	nviSetZoneThresh	UNVT_zone_thresholds	Zone Specifier (1-16) Leak Alarm Threshold (0-65535 PPM) Spill Alarm Threshold (0-65535 PPM) Evacuate Alarm Threshold (0-65535 PPM)	Optional																																																																
	Output	nv2	nviGetZoneThresh	UNVT_zone_specifier	1-16	Optional																																																																
		nv6	nvoHgmAlarmAlert	SNVT_switch	For each type of alert (Any, Leak, Spill, Evac): No Alarm: value=0, state=0 In Alarm: value=200, state=1	Optional																																																																
		nv7	nvoHgmLeakAlert	SNVT_switch		Optional																																																																
		nv8	nvoHgmSpillAlert	SNVT_switch		Optional																																																																
		nv9	nvoHgmEvacAlert	SNVT_switch		Optional																																																																
		nv3	nvoHgmZoneThresh	UNVT_zone_thresholds	Zone (1-16) whose alarm thresholds are displayed Leak Alarm Threshold in PPM (0-65535) Spill Alarm Threshold in PPM (0-65535) Evacuate Alarm Threshold in PPM (0-65535)	Optional																																																																

Operating Limitations When Using MZ-RD Remote Display

When an MZ-RD remote display is used, the FT-10 network will have access to the HGM-MZ as long as the MZ-RD is in either the SYSTEM or ZONE VIEW screen. If the MZ-RD is set to display any other screen, it will respond to polls from the FT-10 adapter with an HGM BUSY exception code. The LonWorks adapter will handle the exception by marking most points as “Unavailable” and setting the Unavailable Reason point to “HGM Busy”. When the MZ-RD is returned to the SYSTEM or ZONE VIEW screen, normal FT-10 network monitoring will resume.

If the operator leaves the MZ-RD in a screen other than SYSTEM or ZONE VIEW for an extended period of time (10 minutes by default), the MZ-RD times out and automatically returns to either the SYSTEM or ZONE VIEW screen. This will restore normal FT-10 network monitoring.

Communications LED Indicators

The communications adapter board has four LED communications status indicators numbered 1-4. See Figure 10 for the locations of these LEDs. The meanings of these indicators are explained below.




Figure 10 – Communications LEDs

Under normal conditions, LEDs 3 and 4 will show a burst of alternating blinks about every 8 seconds. This indicates that the two processors internal to the LonWorks adapter are communicating with each other normally. Occasionally, LEDs 3 and 4 will blink more frequently if commands (to change alarm thresholds, for example) are coming in from the LonWorks network.

LED 1 and LED 2 will normally show activity about every 15 seconds. Since the refrigerant monitoring process is fairly slow and new data is only available every 15 seconds or so, the adapter polls the HGM-MZ at a slow rate to reduce the communications burden on the HGM-MZ main processor. Again, commands coming in from LonWorks might occasionally cause LEDs 1 and 2 to blink more frequently.

NOTE: When the adapter software first starts, it attempts to establish communications with the HGM-MZ before attempting to communicate on the FT-10 network port. Do not be concerned after cycling power or pressing CPU RST that no FT-10 network activity is shown on the LEDs immediately. The software delays about 20 seconds after a restart before attempting to establish FT-10 network communications.

NOTE: The LEDs are driven by adapter software states, not by the RS-485 hardware. If an RS-485 connection stops working in the middle of receiving a message, the RX LED may stay on indefinitely until the connection starts working again.

Troubleshooting

If the adapter seems not to be functioning correctly, it can be restarted without restarting the HGM-MZ simply by pressing the CPU RST button just below the “A” DIP switch. If you restart the adapter by cycling the HGM-MZ’s power, you will have to wait for the HGM-MZ’s 15-minute warm-up cycle to end before PPM readings are available. If restarting the adapter alone doesn’t help, try cycling power to the entire HGM-MZ.

If the adapter is moved to a new LonWorks network where the old addressing information would be invalid, the adapter can be set back to its initial unconfigured state. This is accomplished by holding the service button down, powering up the adapter, and continuing to hold the Service button down for 10 seconds. When the service button is released, the service LED will flash, showing that the LonWorks portion of the adapter is now unconfigured. This is the desired state for installing the adapter on a new LonWorks network.

▽ ▽ ▽