



Multi-Zone Relay Module

HMZ-RM1 (PN #3015-6265)

Installation • Operation • Maintenance

EN 50270:2015

EN 50271

ROHS, REACH, Prop65

MET



Instruction P/N: 3015-6259

Rev. 0

April 2021

Table of Contents

1	INTRODUCTION	3
1.1	About This Manual	3
1.2	Warning and Caution Conventions	3
1.3	Safety Precautions	3
1.4	Components	4
1.5	Dimensions	4
1.6	Specifications	5
2	INSTALLATION	5
2.1	Installation Considerations	5
2.1.1	Warnings and Cautions	5
2.1.2	Inspection	5
2.2	Wiring Diagram	6
2.3	Electrical Wiring	6
2.3.1	Horns/Strobes Wiring	7
2.4	Communications Wiring	8
2.4.1	Multi-Zone Communication Options	8
2.5	Wiring (2) Relay Modules	8
3	SETUP	9
3.1	Enable Service Mode	9
3.1.1	Quit Service Mode	10
3.2	Relay (Rly) Module Setup Menu	11
3.3	Relay Module Setup	12
3.4	Relay Setup	12
3.5	Communications (Comms) Setup Menu	13
3.6	Communications Setup	14
4	GENERAL OPERATION	14
4.1	Functional Overview	14
4.2	Relay Module Status & Faults	15
4.3	Fault Codes	16
5	MAINTENANCE	16
5.1	Cleaning	16

1 INTRODUCTION

1.1 About This Manual


This installation guide is intended to assist in the installation and configuration of the HMZ-RM1, Multi-Zone Relay Module. The HMZ-RM1 is a sixteen channel relay expansion module that integrates with all Multi-Zone Gas Monitors (Firmware 4.00 and newer) and is used to power and control auxiliary horns and strobes for alarming purposes. The HMZ-RM1 interfaces to the Multi-Zone through RS-485 Modbus. The relay configuration is done through the Multi-Zone menu system with each relay able to be assigned to any of the available Multi-Zone channels and can alarm at any of the alarm levels (leak, spill, evacuation) and when a fault occurs. In failsafe mode, the module will also alarm when a loss of power occurs. Each Multi-Zone can be connected to up to two HMZ-RM1 Relay Modules.

1.2 Warning and Caution Conventions

When used in this manual or as **labeled on the relay module**, the following hazard symbols and / or associated words are defined as follows.



WARNING: This symbol and/or the use of the word **WARNING** indicates a potential hazard associated with the use of this equipment. It calls attention to a procedure, practice, condition, or the like, which if not correctly performed or adhered to, could result in death or serious injury.



WARNING: This symbol and/or the use of the word **WARNING** indicates a potential hazard from **electrical shock**. It calls attention to a procedure, practice, condition, or the like, which if not correctly performed or adhered to, could result in death or serious injury.



CAUTION: This symbol and/or the use of the word **CAUTION** indicates a potential hazard associated with the use of this equipment. It calls attention to a procedure, practice, condition, or the like, which if not correctly performed or adhered to, could result in minor or moderate injury.



IMPORTANT: The use of the word **IMPORTANT** in this manual calls attention to a procedure, practice, condition, or the like, which if not correctly performed or adhered to, could result in incorrect performance of or damage to the equipment and may void the warranty.

1.3 Safety Precautions



IMPORTANT: Before using this product, carefully read and strictly follow the instructions in the manual. Ensure that all product documentation is retained and available to anyone operating the instrument. The protection provided by this product may become impaired if it is used in a manner not specified by the manufacturer. Modifications to this instrument, not expressly approved, will void the warranty.



CAUTION: This instrument is neither certified nor approved for operation in oxygen-enriched atmospheres. Failure to comply may result in personal injury or death. **Explosion hazard!** Do not mount the Relay Module in an area that may contain flammable fluids. Operation of any electrical equipment in such an environment constitutes a safety hazard.




CAUTION: In case of malfunction, DO NOT continue to use this equipment if there are any symptoms of malfunction or failure. In the case of such occurrence, de-energize the power supply and contact a qualified repair technician or the nearest Bacharach Service Center.




CAUTION: Use ONLY the provided gland plate for electrical and communication wiring. Drilling into the box will void the warranty.

1.4 Components



1.5 Dimensions



HMZ-RM1	A	B	C	D	E	F	Weight
Metric (mm)	300	400	150	360	345	440	10.0 kg
Imperial (in)	11.8	15.7	5.9	14.2	13.6	17.3	22 lbs

1.6 Specifications

Input Power	100 – 240VAC, 50/60Hz, 4A Protected by 5A fuse/breaker
External Load Capacity (Horns/Strobes)	24VDC, 60W total
Communications	INPUTS: (1) RS-485 Modbus OUTPUTS: (16) General purpose, SPDT relays, rated 24V 3A, configurable
Mounting Distance	Adjacent Remote up to 305 m (1,000 ft)

Warm Up	30 seconds
Enclosure Rating	Indoor Use Only, IP20
Third Party	EN 50270, EN 50271, ROHS, REACH, Prop65, MET
Operating temperature	-20 – 50 °C (-4 to 122 °F)
Operating Humidity	0 to 95% RH (non-condensing)

Recommended Wire Sizes	
Mains power	1.5 mm ² (16 AWG) min.
Relays	0.75 – 0.25 mm ² (18-24 AWG)
Communications	Belden cable #8762 or similar

2 INSTALLATION

2.1 Installation Considerations

2.1.1 Warnings and Cautions



WARNING: Under no circumstances should this product be operated without connection to a protective ground. Failure to comply may result in a potential shock hazard and is a violation of electrical safety standards applicable to this category of equipment.



WARNING: Always remove AC power before working inside the module enclosure and exercise extreme care when accessing the products interior. Only qualified electrical maintenance personnel should perform connections and adjustments.



WARNING: Electrical installation should be performed by a certified electrician, and should comply with all applicable NEC / CEC and local electrical safety codes.



IMPORTANT: A certified AC power disconnect or circuit breaker should be mounted near the module and installed following applicable local and national codes. If a switch is used instead of a circuit breaker, a properly rated CERTIFIED fuse or current limiter is required to be installed as per local or national codes. Markings for positions of the switch or breaker should state (I) for on and (O) for off.

2.1.2 Inspection


The Relay Module has been thoroughly inspected and tested prior to shipment from the factory. Nevertheless, it is recommended that the module be re-checked prior to installation. Inspect the outside of the enclosure to make sure there are no obvious signs of shipping damage. Open the enclosure and inspect the interior of the module for loose components that may have become dislodged during shipment. If damage is discovered, please contact the nearest Bacharach Service Center for assistance.

2.1.3 Mounting Instructions

Dirt, grease, and oils can adversely affect the operation of the Relay Module. The module should be installed out of direct sunlight in a clean, dry area that is not subject to temperature or humidity extremes. Installation of the module in a mechanical room is acceptable provided reasonable environmental conditions exist. If there is a concern, consider installing the unit outside of the mechanical room in a cleaner area of the facility.

1. The module must be mounted to a solid vertical surface or structure capable of supporting the stated weight. It must be positioned where the door can be fully opened and in a location that facilitates easy service and maintenance.
2. The module should be mounted using the mounting bracket kit provided. The bracket bolts are fed through the back of the enclosure to the mounting bracket on the outside. See Section 1.1 for dimensional details.
3. Mounting hardware should be 4mm (1/8") or 5mm (3/16") screws or bolts minimum 40mm (1.5") long with plain washers and suitable wall plugs.
4. It is recommended that the module be located adjacent to the Multi-Zone Gas Monitor that it's connected to. If this is not feasible, the module can be mounted in a remote location.

2.2 Wiring Diagram



2.3 Electrical Wiring

Please see Section 1.6 power and electrical specifications.

The module is equipped with a gland plate, on the bottom of the enclosure, which can be modified in the field with conduit openings/glands. The available gland plate area is 210mm W x 56mm D (8.27" W x 2.2" D). Prior to modification, remove the gland plate by removing the (10) gland plate screws and the gland plate gasket. Once modifications are made, install in the reverse order, ensure the gland plate gasket is properly seated and the gland plate screws are torqued to 1.5 – 2 Nm (1.1 – 1.5 lbft).

Locate the AC input and ground terminals on the inside of the module. Secure the incoming AC power neutral (white/blue) and live (black/brown) wires to the (+) and (-) terminals to the circuit breaker. Secure the AC ground (green) to the terminal adjacent to the circuit breaker.

2.3.1 Horns/Strobes Wiring




WARNING: DO NOT apply Mains voltage to relay terminals




Horns and strobes can be wired to any of the sixteen available relays in the module. Each relay includes NO (Normally Open), COM (Common), and NC (Normally Closed) terminals (T1-16). Wire the horn or strobe to the appropriate terminals for the desired contact type:

MODE	RELAY TERMINALS
FAILSAFE (FS)	COMM-NC
NON-FAILSAFE (NFS)	COMM-NO



The red jumper (J1-16) can be moved to the V_RL and OPEN pins to allow the relay to operate as a dry contact.




Externally derived power can also be applied to the relay output terminals to drive horns and strobes. The external source cannot exceed 30VDC. To wire external power to the relay outputs, remove the red jumper on terminal block T18 by loosening the terminal screws, wire the positive (+) of the external source to the lower terminal as shown above, and wire the negative (-) of the external source to any available terminal on the grounding terminals (terminal block T20 – T25)

2.4 Communications Wiring

The Relay Module can be connected to the Multi-Zone monitor using a shielded twisted pair instrument cable (See Section 1.6 for more details).

Use the provided gland plate to install knockouts and gain access to the interior of the module (See Section 2.3).



2.4.1 Multi-Zone Communication Options

The Multi-Zone Gas Monitor has three available communications ports that can be utilized to connect to the Relay Module:

PORT	REQUIRED ACCESSORY
RS-485 (PORT 1)	NONE
RS-232C (PORT 2)	PN # 3015-6028, RS-232C to RS-485 Adapter Kit
AUX RS-485 (PORT 3)	PN # 3015-6027, RS-485 Lon Socket Adapter Kit


To free the other ports for additional MZ accessories and system integration, the Multi-Zone is set to communicate to the Relay Module via the RS-232C port (RS-232C to RS-485 Adapter required). The port used to communicate with the Relay module can be changed. See Section 3.5 and 3.6 for more details.

See Multi-Zone manual PN #3015-5074 for details on the available ports.

2.5 Wiring (2) Relay Modules

Up to (2) Relay Modules can be wired to a Multi-Zone Monitor.

Follow Section 2.3 and 2.4 for wiring guidance. Once the first Relay Module is installed, a second module can be installed by running power to it in a similar fashion to the first module and daisy chaining the R485 terminals from the first module to the RS485 terminals of the second module.



3 SETUP



CAUTION: Ensure the Multi-Zone Monitor is in Service Mode prior to Relay Module setup. Failure to do so will prevent access to parameters and the ability to save changed parameters.

All setup flow charts start from the Main Data Display Screen of the Multi-Zone monitor. Return to Main Data Display Screen by pressing ESC.




3.1 Enable Service Mode


The default Service Mode Duration is 15 minutes. Service Mode Duration can be changed from 1 – 300 minutes. See Multi-Zone manual PN #3015-5074 for more details on Service Mode.




CAUTION: Multi-Zone must be in Service Mode to configure the Relay Module.
 Service Mode cannot be enable when an alarm is active.
 Service Mode must be exited or timeout for the Multi-Zone to resume functioning properly.



3.1.1 Quit Service Mode



3.2 Relay (Rly) Module Setup Menu



3.3 Relay Module Setup

See Section 3.2 to enter Relay (Rly) Module Setup Screen.

RLY MODULE SETUP

RLY MODULE A UNINSTALLED

RLY MODULE B UNINSTALLED

RLY MODULE A MODBUS ID=10

RLY MODULE B MODBUS ID=20

RLY MODULE A FAILSAFE

RLY MODULE B FAILSAFE

COMMS PORT=2 RS232

RELAY SETUP

BACK

RLY MODULE A UNINSTALLED

RLY MODULE B UNINSTALLED

RLY MODULE A MODBUS ID=10

RLY MODULE B MODBUS ID=20

RLY MODULE A FAILSAFE

RLY MODULE B FAILSAFE

COMMS PORT=2 RS232

RELAY SETUP

Default: DISABLED
Select to Enable/Disable Relay Module
Options: ENABLED, DISABLED

Default: Module A: 10, Module B: 20
Set Relay Module Modbus ID
Options: 10 – 80
(Module A and B cannot be the same address)

Default: FAILSAFE
Set Relay Module as Failsafe/Non-Failsafe
Options: FAILSAFE, NON-FAILSAFE
(See Section 2.3.1)

Select Communication Port for Relay Module
Options: 1 (RS485), 2 (RS232), 3 (AUX485)
Default: 2

Select to configure all relays on Enabled Relay Modules.
(See Section 3.4 for more detail)

NAVIGATE / TOGGLE

ENTER

SELECT / SAVE

3.4 Relay Setup

See Section 3.2 to enter the Relay (Rly) Module Setup Screen. Each Relay Module is equipped with sixteen programmable relays. Relay Module A, Relay 2 (A02) shown below. The first twelve relays are shown when accessing the Relay Setup Screen. Default relay settings shown below.

See Multi-Zone manual PN #3015-5074 for more information on zones and TRIG alarms.

IMPORTANT: Press ► or ◀ to toggle between RLY A SETUP (Module A) and RLY B SETUP (Module B), if multiple Modules are wired to the Multi-Zone monitor

IMPORTANT: When ANY is selected for a zone, the relay state will change when any zone's TRIG criteria has been met

NAVIGATE / TOGGLE

ENTER

SELECT / SAVE

ZONE

Default: Relay 2 (A02) = Zone 2 (Z02)

Select Zone corresponding to relay

Options: Z01-Z16, ANY, NONE

▲

▼

RLY	ZONE	TRIG	STATE
A01	Z01	EVAC	NORMAL
A02	Z02	EVAC	NORMAL
A03	Z03	EVAC	NORMAL
A04	Z04	EVAC	NORMAL
A05	Z05	EVAC	NORMAL
A06	Z06	EVAC	NORMAL
A07	Z07	EVAC	NORMAL
A08	Z08	EVAC	NORMAL
A09	Z09	EVAC	NORMAL
A10	Z10	EVAC	NORMAL
A11	Z11	EVAC	NORMAL
A12	Z12	EVAC	NORMAL

STATE

Default: NORMAL

Shows current relay state

Options: NORMAL, ACTIVE

ENTER

 3 secs to test

TRIG

Default: EVAC


Select alarm/fault that triggers relay

Options: EVAC, SPILL, LEAK, FAULT

▲

▼

3.5 Communications (Comms) Setup Menu



3.6 Communications Setup

Default Relay Module Modus Parameters shown. See Multi-Zone Manual PN #3015-5074 for more information.

MULTI-ZONE

COMMS SETUP


PORT 1 - RS485
BAUD = 19200
PARITY = NONE
STOP = 1

PORT 3 - AUX485
DISABLED
BAUD = 19200
PARITY = NONE
STOP = 1
TERM = NO

PORT 2 - RS232
BAUD = 19200
PARITY = NONE
STOP = 1

BACK

RELAY MODULE DIP SWITCH



Switch Pos.	Function	Default	10	20	30	40	50	60	70	80
1	Modbus Address	Off	Off	Off	Off	On	On	On	On	Off
2		Off	Off	On	On	Off	Off	On	On	Off
3		On	On	Off	On	Off	On	Off	On	Off
4	Reserved									
5	Reserved									
6	Word Format	Off	6=Off, 7=Off		6=Off, 7=On		6=On, 7=Off		6=On, 7=On	
7		Off	8,N,1		8,N,2		8,O,1		8,E,1	
8	Baud Rate	On	Off=9600 bps				On=19200 bps			

NAVIGATE / TOGGLE
 SELECT / SAVE

4 GENERAL OPERATION

4.1 Functional Overview



CAUTION: Once a relay module is enabled and connected to a Multi-Zone monitor is cannot be easily disable/disconnect. Please contact Bacharach Product Support for additional assistance.

By way of a RS485 connection, the Multi-Zone Relay Module expands the available alarm relays of the Multi-Zone Gas Monitor from (4) to (36) relays with a maximum of (2) modules per monitor. With a possibility of (32) additional relays, a multitude of horns and strobes can be deployed throughout a facility to readily alert personnel to a leak or fault occurrence.

Once operational, the Relay module communicates visually to the user via LED lights on the Relay Module board.

LED COLOR	STATE	DESCRIPTION
GREEN	STEADY	Power applied to Module
	FLASHING	Communication Received/Transmitted
AMBER	FLASHING	Heartbeat, once per second
RED	STEADY	Fault or Loss of Communications



4.3 Fault Codes

See Section 4.2 to access Relay Module Status and Faults

FAULT	CODE	DESCRIPTION
Firmware Fault	<0001>	Error detected in firmware
Voltage out of specification 3.3V	<0002>	3.3V out of range
Voltage out of specification 24V	<0004>	24V out of range
Relay Fault	<0008>	Relay state does not match expected state
Modbus Fault	<0010>	Error detected in Modbus communications
Temperature Fault	<0020>	Measured temperature is outside of limits
RAM Integrity Fault	<0040>	Error detected during RAM test

5 MAINTENANCE

A technician with the use of readily available hand tools and factory provided instructions can perform basic diagnostics, replace subcomponents, and confirm proper operation before putting the unit back into service. Field upgrade is possible with proper equipment.

SPARE PARTS	
PART NUMBER	DESCRIPTION
3015-6251	Relay Board
3015-6256	Circuit Breaker, 2-Pole, 4A, 250V
3015-6254	Power Supply, 24V

5.1 Cleaning

When required, cleaning of the HMZ-RM1 should be performed using a clean, dry cloth on the outside of the enclosure. To avoid shock hazard and/or equipment damage, DO NOT use soap and water.

WARRANTY

Bacharach, Inc. warrants to Buyer that at the time of delivery this Product will be free from defects in material and manufacture and will conform substantially to Bacharach Inc.'s applicable specifications. Bacharach's liability and Buyer's remedy under this warranty are limited to the repair or replacement, at Bacharach's option, of this Product or parts thereof returned to Seller at the factory of manufacture and shown to Bacharach Inc.'s reasonable satisfaction to have been defective; provided that written notice of the defect shall have been given by Buyer to Bacharach Inc. within two (2) years after the date of delivery of this Product by Bacharach, Inc.

Bacharach, Inc. warrants to Buyer that it will convey good title to this Product. Bacharach's liability and Buyer's remedy under this warranty of title are limited to the removal of any title defects or, at the election of Bacharach, to the replacement of this Product or parts thereof that are defective in title.

The warranty set forth in Paragraph 1 does not apply to parts that the Operating Instructions designate as having a limited shelf-life or as being expended in normal use (e.g., filters).

THE FOREGOING WARRANTIES ARE EXCLUSIVE AND ARE GIVEN AND ACCEPTED IN LIEU OF (I) ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE; AND (II) ANY OBLIGATION, LIABILITY, RIGHT, CLAIM OR REMEDY IN CONTRACT OR TORT, WHETHER OR NOT ARISING FROM BACHARACH'S NEGLIGENCE, ACTUAL OR IMPLIED. The remedies of the Buyer shall be limited to those provided herein to the exclusion of any and all other remedies including, without limitation incidental or consequential damages. No agreement varying or extending the foregoing warranties, remedies or this limitation will be binding upon Bacharach, Inc. unless in writing, signed by a duly authorized officer of Bacharach.

**Register your warranty by visiting
www.mybacharach.com**

Product improvements and enhancements are continuous; therefore the specifications and information contained in this document may change without notice.

Bacharach, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Copyright © 2021, Bacharach, Inc., All Rights Reserved

No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Bacharach, Inc.

BACHARACH® is a registered trademark of Bacharach, Inc. All other trademarks, trade names, service marks and logos referenced herein belong to their respective owners

